


Straight, 50/100W - neues Netzteil / new power supply



Sicherungen / Fuses	Istraight	Istraight	I
	I 50 W	I 100 W	I
-----I-----I-----I			
ext. 100/120 V	I 3,15AT	I 5 AT	I
220/240 V	I 1,6 AT	I 2,5AT	I
-----I-----I-----I			
internal 2x	I 2,5 AT	I 3,15AT	I
-----I-----I-----I			
Anode 2x	I 0,5 AT	I 1,25AT	I
-----I-----I-----I			

Rx: mit diesem Widerstand Ruhestrom der Endstufe Einstellen
 adjust the Bias with this resistor
 (Wert zwischen / value between 15 K und 27 K)