



## INDUCTOR SVT2

CORE RM8 UNGAPPED

MATERIAL F5, N67, 3C85, F44

### Coil 1

Wind 110 TURNS using 0.125mm Dia PUR

**Wind tightly**

Start 1, S1 pin 2

Tap 1, T1 pin 1

Wind 80 TURNS using 0.125mm Dia PUR

**Wind tightly**

Tap 2, T2 pin 11

Wind 55 TURNS using 0.125mm Dia PUR

**Wind tightly**

Finish 1, F1 pin 12

Wind around coil with thin tape.

Assemble core halves, with RM8 ungapped core halves

Label with IND-SVT rev 1

