
INPUT
Treble
Bass
Master
Send
Return
FX Loop
Balance
Standby
Fuse
external internal
230 Volts 1,25 AT 1,6 AT
117 Volts 2,5 AT 3,15 AT
BIAS ADJUSTMENT:
DC-VOLTAGE BETWEEN
A AND C: 1,6-2,2 Volts
B AND C: 1,6-2,2 Volts
Stand By On: 430 Volts
Stand By Off: 450 Volts
ENGL Gerätebau GmbH
325